

# ICX Spanning Tree Commands

## Introduction

Best practice switch port configuration for trunk and access ports.

## Method

Apply the below config line at EXEC level globally.

```
system-max spanning-tree 253
```

Apply the below configs on a port/interface level as per switch port mode.

### Trunk Port

```
spanning-tree 802-1w admin-pt2pt-mac
```

### Access Port

```
spanning-tree 802-1w admin-edge-port
```

---

Revision #1

Created 9 August 2024 06:04:55 by Jarryd

Updated 9 August 2024 06:05:53 by Jarryd