ICX Spanning Tree Commands

Introduction

Best practice switch port configuration for trunk and access ports.

Method

Apply the below config line at EXEC level globally.

system-max spanning-tree 253

Apply the below configs on a port/interface level as per switch port mode.

Trunk Port
spanning-tree 802-1w admin-pt2pt-mac

Access Port
spanning-tree 802-1w admin-edge-port

Revision #1
Created 9 August 2024 06:04:55 by Jarryd
Updated 9 August 2024 06:05:53 by Jarryd